

INSIDE MOUNT	
<p>*Elite will make necessary deductions to fit the window opening.</p>	
Width	Height
<p>Measure the exact width of the inside edge of the window frame in 3 places (top, middle, bottom) left to right. Take the smallest size of the three measurements and write that measurement on your order.</p>	<p>Measure the exact height of the inside edge of the window frame in 3 places (top to bottom). Take the smallest of the 3 measurements and write that measurement on your order.</p>

OUTSIDE MOUNT	
<p>*Determine where you want to install the shade. Ensure you have approximately 2 1/2" of clearance (flat surface) to install the product either on top of the frame or above the frame on the wall.</p>	
Width	Height
<p>Measure the outer edge of the left hand moulding to the outer edge of the right hand moulding. To minimize light gaps and for additional privacy, add extra inches for coverage on each side of the window.</p>	<p>Measure the top edge of the moulding to the bottom edge of the moulding. Add extra inches (for hardware height) to the overall shade height ensuring coverage for the install.</p>

Measuring Tips	Choose Mount Type	Measure	Write it Down
<p>Use a metal measuring tape or laser measuring tool</p>	<p>Inside Mount      Outside Mount</p>	<p>Round down to the nearest 1/8" for width</p> <p>Round down to the nearest 1/8" for height</p>	<p>Enter measurements</p>

